

# Sprinkler Operation



The outdoor ring is watered using an automated underground sprinkler system. The ring is watered before outdoor arena maintenance. Please feel free to water the ring as needed throughout the day. Please warn other riders before running the system. There are 7 sprinkler heads. The system runs one sprinkler head at a time.

1. Begin from the **RAIN-OFF** position. This resets the system. If the dial is already set to **RAIN-OFF** when you open the controller box go to step 2, otherwise turn the dial to **RAIN-OFF**.

2. Select the amount of time you wish to water (3 minutes is the usual time to water):
  - **A:** 3 minutes per sprinkler head total of 21 minutes
  - **B:** 4 minutes per sprinkler head total of 28 minutes
  - **C:** 2 minutes per sprinkler head total of 14 minutes
  - **D:** 1 minute per sprinkler head total of 7 minutes
3. Turn the dial to **MANUAL PROGRAM CYCLE**
4. Press the **ON** button

If you have a problem you may press the **OFF** button at any time.

Press the **NEXT** button to manually move to the next sprinkler.

*Caution: Do Not Over Water*

---

---

If you have any problem with the system notify  
Rosemary Nero at the Park District Office:

(847)783-6772

---

---